
















# SINGER® HD6800







## English






English				
1	STRAIGHT STITCH	Seams		The most common use for the straight stitch is for joining fabrics together with a seam. The machine needle plate has a series of etched markings to the right of the presser foot which serve as guidelines for various widths of seam allowances when sewing with the needle in center position. Line up the raw edges of the fabric with the desired seam allowance guideline to sew a seam.
2	STRAIGHT STITCH	Quilt Piecing		Quilt piecing is done using a 1/4" seam allowance. After sewing, press seams toward the darker of the two fabrics, to help prevent the seam allowance from being visible on the top side of the quilt. It may be helpful to use a Quarter Inch Foot (additional accessory for some machine models).
3	STRAIGHT STITCH	Topstitching		Topstitching is a line of straight stitching on the outside of a garment or project, usually as a decorative embellishment. Set the machine for straight stitch, with a stitch length of 3 to 3.5mm. Sew 1/4" - 3/8" from the edge of the fabric. If sewing with topstitching thread, use a SINGER Topstitching Needle, size 90/14 for medium weight fabrics, or a SINGER Topstitching needle, size 100/16 for heavier fabrics. A Topstitching Needle (additional accessory) has a longer eye to accommodate thicker threads, such as topstitching thread which gives the stitches a bolder look.
4	STRAIGHT STITCH	Edge Stitching		Edgestitching can be used to add stability to projects like tote bags, or it can be used simply as a decorative embellishment. Set the machine for straight stitch. Sew approximately 1/8" from the edge of the fabric.
5	STRAIGHT STITCH	Basting		Basting stitches are used to temporarily hold fabrics together, for example, when you want to check the fit of a garment before sewing the actual seam. To set the machine for basting, if your machine has adjustable stitch length, select straight stitch with the longest stitch length setting. It is helpful to also slightly reduce the upper thread tension as well (this makes it easier to remove the temporary basting stitches later). Sew the row of basting stitches, and check the fit of the garment. When satisfied with fit, select the stitch length setting as needed for the project, and be sure to put the upper thread tension back to its original position. Sew the permanent seam. Remove the temporary basting stitches.






English				
6	STRAIGHT STITCH	Decorative Stitching		The basic straight stitch can be used to embellish fabrics. Experiment with various thread types to create your own unique design. It can be helpful to draw stitch guidelines on the fabric with a removable fabric marking tool, but make sure to use a fabric marker that is appropriate for the type of fabric being sewn.
7	STRAIGHT STITCH	Free-Motion Quilting		Free-motion quilting means stitching together a backing fabric, batting, and top fabric, and the straight stitch is used to sew decorative designs as the layers are quilted together. To set the machine for free-motion quilting, first disengage or cover the machine's feed teeth (see your machine's manual for details). Remove the presser foot and presser foot holder. Attach a Darning / Embroidery Foot (additional accessory for some machine models). Select straight stitch. Move the fabric layers together manually as you stitch. For more information on free-motion sewing, see this video.
8	STRAIGHT STITCH	Thread Painting		Thread painting is a type of free-motion sewing. Multiple thread colors can be layered to create colorful images. To set the machine for thread painting, first disengage or cover the machine's feed teeth (see your machine's manual for details). Remove the presser foot and presser foot holder. Attach a Darning / Embroidery Foot (additional accessory for some machine models). Select straight stitch. Place stabilizer or batting underneath the fabric. Move the layers together manually as you stitch. For more information on thread painting and free-motion sewing, see this video.
9	STRAIGHT STITCH	Channel Quilting		Create dimension in quilt layers by sewing several rows of stitches spaced apart. For best results, use an Even Feed / Walking Foot (additional accessory for some machine models), which will help prevent the quilt layers from shifting as you sew.
10	STRAIGHT STITCH	Echo Quilting		Echo quilting is sometimes called 'outline quilting'. This is done by following around the shape of an applique, a design printed in the fabric itself, or perhaps even an embroidery on the fabric. Set the machine for straight stitch. The thread color can either match the fabric, or it can be a contrast color, depending on the look you want. Sew the desired number of "rows" around the design to create interesting texture.
11	STRAIGHT STITCH	Attaching Trims		Attach ribbons and trims to embellish fabrics. To attach a ribbon or trim, set the machine for straight stitch. When stitching wider trims or those that tend to shift on top of the fabric while sewing, it can be helpful to use a fusible basting tape to hold it in place.

English				
12	STRAIGHT STITCH	Raw Edge Applique		Raw edge applique is one of the simplest ways to do machine applique, providing an organic appearance. First adhere the applique to the base fabric with fusible web. Stitch around the applique with a straight stitch, approximately 1/8" from its raw edge. Note: It can be helpful to use an Open Toe Foot (additional accessory for some machine models) so you have a more clear view of the stitching area.
13	STRAIGHT STITCH	Twin Needle Pintucks		Pintucks are used for texture on lightweight fabrics such as batiste. To create pintucks, set machine for straight stitch. Insert a SINGER Universal Twin Needle 1.6mm or 2.0mm (additional accessory). It is helpful to use a Pintuck Foot (additional accessory for some models). Place one thread spool on the main spool pin, and a second spool of thread on the auxiliary spool pin, with threads unreeling in opposite directions so they don't tangle while sewing. Note: If machine has no auxiliary spool pin, it may be helpful to use an external cone stand (additional purchase). Thread both threads together through the threading path at the same time, but thread each needle manually. Increase needle thread tension for more enhanced tucks. Here is a video for the Pintuck Foot, which includes twin needle pintuck stitching.
14	STRAIGHT STITCH	Twin Needle Hems		Twin needle hems provide a professional finish to garments. The top side has two parallel rows of straight stitching, connected with a zigzag on the back side. Twin needles (additional accessory) come in many of sizes, so choose one that provides the look you want for your project. Place one thread spool on the main spool pin, and a second spool of thread on the auxiliary spool pin, with threads unreeling in opposite directions so they don't tangle while sewing. Note: If machine has no auxiliary spool pin, it may be helpful to use an external cone stand (additional purchase). Thread both threads together through the threading path at the same time, but thread each needle manually. Turn the hem up and stitch from the top side, catching the raw edge as you sew.
15	STRAIGHT STITCH	Gathering		Gathering takes a longer piece of fabric and shortens it by creating a series of small folds, used to create fullness. Gathers can be created various ways. For medium weight fabrics, set the machine for straight stitch with a long length setting, and then reduce the upper thread tension. Sew one row of stitches just inside the seam guide line, then sew another row about 1/8" next to that inside the seam allowance. Pull the bobbin threads to gather the fabric. For lightweight fabrics, use this same method, or try using a Gathering Foot (additional accessory). For more information about the Gathering Foot, see this video.




English				
16	STRAIGHT STITCH	Pleating		Pleating is creating a series of consistently sized folds in fabric, creating fullness. Use the straight stitch, along with a Ruffler (additional accessory for some models) to sew evenly spaced pleats. Instead of manually pressing and basting the pleats individually, the Ruffler does all the work for you. See how to use the Ruffler to achieve various types of pleats and gathers in this video.
17	STRAIGHT STITCH	Zipper Insertion		The main types of zipper insertion are the centered zipper, the lapped zipper and the fly front zipper. All these methods are done using the basic Zipper Foot (additional accessory for some machine models). There is another method zipper insertion method called the invisible zipper, for which an Invisible Zipper Foot (additional accessory for some machine models) is used. See this video for using the basic Zipper Foot, and this video for how to use the Invisible Zipper Foot.
18	STRAIGHT STITCH	Creating Piping		There are times you may want to create your own piping, particularly if you want a specific color of piping for your project. Cut a fabric strip wide enough to wrap around the cord as well as provide ample seam allowance. The fabric strip should be cut on the bias, which will make it easy to insert the piping at corners and curves without puckering. Set the machine for straight stitch. Use a Zipper Foot (additional accessory for some machine models) to help sew closer to the piping. There is a demonstration of this in our Zipper Foot video.
19	STRAIGHT STITCH	Inserting Piping		Piping can be used in home decor, fashion and accessory sewing, and more. It can be purchased pre-made in packages, or you can make it yourself. To insert piping, sandwich the piping between the fabric layers, with the bulk of the piping on the left side. It may be helpful to baste the layers together before stitching them at the machine. Set the machine for straight stitch and attach the Zipper Foot (additional accessory for some machine models). There is a demonstration of this in our Zipper Foot video.
20	STRAIGHT STITCH	Narrow / Rolled Hems		Very narrow hems can be stitched at the edge of light to medium weight fabrics using a Narrow Hem Foot, sometimes called a Rolled Hem Foot (additional accessory for some machine models). This foot has a small scroll in front that feeds the fabric while the machines sews a straight stitch to secure the hem in place. See this video for information on using the Narrow/Rolled Hem Foot.
21	STRAIGHT STITCH	Topstitched Hems		Sew simple hems using a straight stitch. The stitches will be seen on both the top side and back side of your project. Use a thread that matches the fabric for a hem that is less noticeable, or choose a contrasting thread for a bold appearance.

English				
22	STRAIGHT STITCH	Understitching		Understitching is used to help prevent a waistline or neckline facing from rolling to the outside. Set the machine for straight stitch. Sew through the facing and seam allowance only. The understitching will not be visible from the outside of the project.
23	STRAIGHT STITCH	Stay Stitching		Sleeves, necklines, and princess seams are curved and can become distorted and difficult to join to the rest of the garment. Stay-stitching is used to help stabilize fabric by preventing stretching and distortion. Set the machine for straight stitch. Sew just inside the seam allowance.
24	STRAIGHT STITCH	Darning		Small holes or tears in fabric can be repaired using a Darning / Embroidery Foot (additional accessory for some machine models) and the straight stitch. Place a small piece of fabric behind the area to be repaired. Set the machine for straight stitch, cover or disengage the feed teeth (check your machine manual), and thread the machine with a color that blends well with the fabric. Manually move the fabric in a back-and-forth motion as you step on the foot control. There is a demonstration of darning in our Darning/Embroidery Foot video.
25	STRAIGHT STITCH LEFT POSITION	Seams		The most common use for the straight stitch is for joining fabrics together with a seam. When sewing with the needle in left position, more of the fabric is under the presser foot than if sewing in center needle position, which can help the fabric feed smoothly when sewing some fabrics.
26	STRAIGHT STITCH LEFT POSITION	Topstitching		Topstitching is a line of straight stitching on the outside of a garment or project, usually as a decorative embellishment. The left position straight stitch can be used to sew topstitching on projects like coats, jackets and tote bags. Because the needle is in left position, more of the fabric is under the presser foot, offering stable fabric feed. Use a SINGER Topstitching Needle, size 90/14 for medium weight fabrics, or a SINGER Topstitching needle, size 100/16 for heavier fabrics. A Topstitching Needle (additional accessory) has a longer eye to accommodate thicker threads, such as topstitching thread which gives the stitches a bolder look. Sew 1/4" - 3/8" from the edge of the fabric.
27	STRAIGHT STITCH LEFT POSITION	Edge Stitching		Edgestitching can be used to add stability to projects like tote bags, or it can be used simply as a decorative embellishment. Select the left position straight stitch. Sew approximately 1/8" from the edge of the fabric. It can be helpful to use the Blind Hem Foot (additional accessory for some machine models) as a guide for the edge of the fabric, adjusted to help you sew straight along the edge.

English				
28	STRAIGHT STITCH LEFT POSITION	Zipper Insertion		The left position straight stitch can be used to aid with zipper insertion. The main types of zipper insertion are the centered zipper, the lapped zipper and the fly front zipper. All these methods are done using the basic Zipper Foot (additional accessory for some machine models).
29	STRAIGHT STITCH LEFT POSITION	Creating Piping		There are times you may want to create your own piping, particularly if you want a specific color for your project. Cut a fabric strip wide enough to wrap around the cord as well as provide ample seam allowance. The fabric strip should be cut on the bias, which will make it easy to insert the piping at corners and curves without puckering. Select the left position straight stitch. Use a Zipper Foot to help sew closer to the piping. With the needle in left position, it will be possible to sew closer to the cord which will provide a more snug fit.
30	STRAIGHT STITCH LEFT POSITION	Inserting Piping		Piping can be used in home decor, fashions and accessories, and more. It can be purchased pre-made in packages, or you can make it yourself. To insert piping, sandwich the piping between the fabric layers. It may be helpful to baste the layers together before stitching them at the machine. Set the machine for straight stitch and attach the Zipper Foot. With the needle in left position, it is possible to sew close to the cord, providing a more snug fit.
31	ZIGZAG STITCH	Seam Finishing		The zigzag stitch can be used as a seam finish to help prevent fabric edges from unraveling. If your machine has adjustable stitch length and stitch width, select a medium stitch length and width - using a width that is too wide may cause the fabric edge to tunnel under the presser foot.
32	ZIGZAG STITCH	Applique		The most popular stitch for machine applique is the satin stitch, created using a zigzag stitch. The stitches are sewn around the edge of the applique to attach it to the main fabric. The right movement of the needle sews just off the edge of the applique, and the left movement of the needle sews into the applique. If your machine has adjustable stitch length and stitch width, try experimenting on scrap fabric to find the exact settings you want for your applique. Set the width at a medium setting to start, and adjust from there. The stitch length setting should be short enough so that you don't see fabric between the stitches, but not so short that the stitches don't feed under the foot. It can also be helpful to use a Satin Stitch Foot (additional accessory for some machine models), which has a groove on the bottom to allow dense stitching to pass freely underneath.





English				
33	ZIGZAG STITCH	Couching		Create interesting surface embellishment using the zigzag stitch to sew over lightweight cords or yarns. If your machine has adjustable stitch width and stitch length, choose a stitch width setting that is wide enough to cover the cord, without actually stitching into the cord. Choose a stitch length setting that is long enough to see the cord without covering it up. It can be helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear area in front of the needle as you sew. Use a slow speed and take your time for maximum control.
34	ZIGZAG STITCH	Decorative Stitching		Sew the zigzag stitch to create texture in fabric. Experiment with various thread types and colors. If your machine has adjustable stitch length and stitch width, try different settings to customize the look you want for your project. For denser stitches such as when sewing a satin stitch, use a Satin Stitch Foot (additional accessory for some machine models). If using thicker threads such as 12wt cotton, use a larger size needle so that the thread passes freely through it. It is recommended to use a stabilizer underneath the fabric to help support the stitches.
35	ZIGZAG STITCH	Attaching Trims		Use the zigzag stitch to sew over ribbons and trims. It's an easy way to embellish projects. Set the zigzag width based on the width of the ribbon. If your machine has adjustable stitch length, the stitch length should be set at a fairly long setting so the ribbon is visible between the stitches. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area.
36	ZIGZAG STITCH	Sewing on Buttons		Use the zigzag stitch to attach buttons. Disengage or cover the machine's feed teeth (see your machine manual). It is helpful to use the Button Sewing Foot (additional accessory for some machine models) which helps hold the button securely and provides a clearer view of the stitching area than does the All-Purpose Foot. Place the button on the fabric underneath the foot. Set the machine for a zigzag stitch. Turn the handwheel toward you slowly to check that the left and right movement of the needle clears the button's holes. If the needle doesn't clear both holes, adjust stitch width (if your machine has adjustable stitch width) accordingly until it does. Sew several stitches to attach button. Bring thread tails to back of fabric and tie to secure. For more information, see this video.
37	ZIGZAG STITCH	Elastic Insertion		Insert elastic easily with the zigzag stitch. For elastic that is 1/4" - 3/8" wide, place the elastic through the opening of the All-Purpose Foot. This will help keep the elastic from slipping from left to right as you sew. Hold the elastic from in front and in back of the presser foot, stretching the elastic as you do so.

## English




38	ZIGZAG STITCH	Gathering		<p>For some fabrics, gathering can be a challenge. Try using your machine's zigzag stitch to create a "casing" over a cord. Place a knot at one end of the cord. For machines with adjustable stitch width, select a width setting that is wide enough to cover the cord, but not actually stitch the cord itself. If the machine has adjustable stitch length, select a fairly long stitch length setting. It is helpful to use a Cording Foot (additional accessory for some machine models), which has a groove to guide the cord easily as you stitch the zigzag. When stitching is done, pull the cord to gather the fabric. See a demonstration of this technique in the Cording Foot video.</p>
39	ZIGZAG STITCH	Free-Motion Monograms		<p>Create monograms in any size or style by moving your fabric in free-motion mode. To set the machine for free-motion monograms, first disengage or cover the machine's feed teeth (see your machine's manual for details). Remove the presser foot and presser foot holder. Attach the Darning/Embroidery Foot (additional accessory for some machine models). Select the zigzag stitch. Place a piece of stabilizer underneath the fabric to give the stitches added support. It may be helpful to draw your monogram on the main fabric using a removable fabric marker, to help guide you. Move the layers together manually as you stitch. For more information on free-motion sewing, see this video.</p>
40	ZIGZAG STITCH	Thread Painting		<p>Thread painting is a type of free-motion sewing. Multiple thread colors can be layered to create colorful images. To set the machine for thread painting, first disengage or cover the machine's feed teeth (see your machine's manual for details). Remove the presser foot and presser foot holder. Attach the Darning / Embroidery Foot (additional accessory for some machine models). Select the zigzag stitch. For machine models with adjustable stitch width, adjust the stitch width as desired for your project. Place batting or stabilizer under the fabric. Move the layers together manually as you stitch. For more information on thread painting and free-motion sewing, see this video.</p>









## English





41	ZIGZAG STITCH	Roll & Whip Heirloom Hems		<p>Heirloom sewing incorporates several different techniques, and one of these techniques is the Roll &amp; Whip Hem, done using a zigzag stitch. This hem works on fine, lightweight fabrics like batiste. Thread the machine with lightweight thread. A size 9/70 or 11/80 needle (additional accessory for some machine models) is recommended. Set the machine for zigzag stitch. For machines with adjustable stitch length and stitch width, use with a width setting of at least 5.0mm and a length setting of approximately 2.0mm. Use an Open Toe Foot (additional accessory for some machine models) so that the area in front of the needle is unobstructed. Position the fabric so the right movement of the zigzag goes off the edge of the fabric. As the stitch then moves to the left, it "rolls" the fabric over, stitching it in place.</p>
42	ZIGZAG STITCH	Attaching Hook Closures		<p>Use the zigzag stitch to attach some larger sizes or styles of hook and eye closures. Disengage or cover the machine's feed teeth (see your machine manual). Select the zigzag stitch. For sewing larger sized hook &amp; eye closures, attach the Button Sewing Foot (additional accessory for some machine models) which helps hold each side of the closure securely and provides a clearer view of the stitching area than does the All-Purpose Foot. Place the closure piece on the fabric underneath the foot. Turn the handwheel toward you slowly to check that the left and right movement of the needle clears the closure piece. If the needle doesn't clear both holes, adjust stitch width (if your machine has adjustable stitch width) accordingly until it does. Sew several stitches to attach. Bring thread tails to back of fabric and tie to secure.</p>
43	ZIGZAG STITCH	Hemstitching		<p>Hemstitching is a sewing technique used to create delicate heirloom hems. Sew beautiful hemstitching using a simple zigzag stitch and a SINGER size 90 Wing Needle (additional accessory for some machine models). For machines with adjustable stitch length and stitch width, set the stitch width at 3.0mm and the stitch length at 2.0mm. Turn up the hem allowance and sew, catching the raw edge of the hem as you go. The needle will make small holes in the fabric, creating a delicate finish. Best results come when sewing organdy, organza or batiste. A fabric spray starch can make fabrics easier to manage, as well.</p>
44	ZIGZAG STITCH	Lettuce Edging		<p>Sew a zigzag stitch to create a "wavy" hem, sometimes called a "lettuce edge". This technique is for stretch knit fabrics such as t-shirt or jersey. Set the machine for the zigzag stitch. For machines with adjustable stitch length and stitch width, select a medium stitch length and stitch width setting. Sew along the raw edge of the fabric, stretching the fabric from both front and back as you go. When you release the fabric, the result is a wavy, curly edge.</p>

## English






45	ZIGZAG STITCH	Attaching Lace		<p>Heirloom sewing incorporates several different techniques, and one is to attach lace using a zigzag stitch. This works on fine, lightweight fabrics like batiste and lace that has a flat edge on one side. Thread the machine with lightweight thread. A size 9/70 or 11/80 needle (additional accessory for some machine models) is recommended. Set the machine for zigzag stitch. For machines with adjustable stitch length and stitch width, select a width setting of at least 5.0mm and a length setting of approximately 2.0mm. Use an Open Toe Foot (additional accessory for some machine models) so that the area in front of the needle is unobstructed. Position the lace on top of the fabric about 1/8" to the left of the fabric edge, then position this so the right movement of the zigzag goes off the edge of the fabric and the left movement catches the flat edge of the lace. As the stitch then moves to the left, it "rolls" the fabric over, stitching it to the lace.</p>
46	ZIGZAG STITCH	Edge Joining		<p>Two fabrics can be joined together using a zigzag stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (additional accessory for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. Select the zigzag stitch. For machines with adjustable stitch length and stitch width, select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle (additional accessory for some machine models) for a bolder appearance to the stitches.</p>
47	MULTI-STEP ZIGZAG STITCH	Mending		<p>Holes, rips or tears in fabric can be repaired easily with the multi-step zigzag stitch. This stitch sews 3 small stitches each time it moves left to right and right to left. For machines with adjustable stitch length and stitch width, set the machine for a wide stitch width and shorter stitch length setting. Place a small piece of fabric (that blends well with the main fabric) underneath the hole or tear. Sew the stitch across the tear. Repeat until the hole or tear is sufficiently covered with stitches.</p>

English				
48	MULTI-STEP ZIGZAG STITCH	Decorative Stitching		The multi-step zigzag sews 3 small stitches each time it goes left to right and right to left, which can create a unique decorative element. Create interesting texture and surface embellishment for your fabrics by sewing multiple rows of this stitch. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using. Learn more about needles on the SINGER website.
49	MULTI-STEP ZIGZAG STITCH	Couching		Use the multi-step zigzag stitch, along with a Cording Foot, to add interesting surface dimension to your projects. The Cording Foot (additional accessory for some machine models) has grooves on top that help guide thin yarns or cords as you stitch over them. The stitch "catches" the cords to secure them to the fabric surface. It is helpful to use a tear-away stabilizer underneath as you sew to help prevent fabric puckering.
50	MULTI-STEP ZIGZAG STITCH	Elastic Insertion		The multi-step zigzag sews 3 small stitches each time it goes left to right and right to left, making this stitch strong yet flexible. Use it to easily sew elastic onto fabric. For elastic that is 1/4" - 3/8" wide, place the elastic through the opening of the All-Purpose Foot. This will help keep the elastic from slipping from left to right as you sew. Hold the elastic from in front and in back of the presser foot, stretching the elastic as you do so.
51	MULTI-STEP ZIGZAG STITCH	Attaching Trims		Use the multi-step zigzag stitch to attach ribbons and trims. It's an easy way to embellish projects. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area. For machines with adjustable stitch length or stitch width, set the stitch length and stitch width according to the look you want for your project.
52	MULTI-STEP ZIGZAG STITCH	Seam Finishing		The multi-step zigzag stitch can be used as a seam finish to help prevent fabric edges from unraveling. For machines with adjustable stitch length and stitch width, select a medium stitch length and width and sew along the raw edge of the fabric to finish the edge.
53	MULTI-STEP ZIGZAG STITCH	Bartacks		A bartack is a series of stitches used to reinforce high-stress areas of garments such as belt loops, pockets, zippers, etc. The multi-step zigzag sews 3 small stitches each time it goes left to right and right to left. When stitch length is set to "0", or if the machine's feed teeth are either covered or disengaged, the stitch can be used to sew bartacks,





## English

54	MULTI-STEP ZIGZAG STITCH	Edge Joining		<p>Two fabrics can be joined together using a multi-step zigzag stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (additional accessory for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. Select the multi-step zigzag stitch. For machines with adjustable stitch length or stitch width, select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle (additional accessory for some machine models) for a bolder appearance to the stitches.</p>
55	MULTI-STEP ZIGZAG STITCH	Joining Batting		<p>Use the multi-step zigzag stitch to join pieces of batting to create a larger batting piece. It's great for creating a custom sized quilt or other quilted projects, and also a great way to use up smaller batting leftovers. The multi-step zigzag sews 3 small stitches each time it goes left to right and right to left, which helps make the join secure. Use the widest stitch width possible for maximum coverage.</p>
56	BLIND HEM STITCH	Blind Hemming		<p>Use a Blind Hem Foot (additional accessory for some machine models) in conjunction with your machine's blind hem stitch to sew hems that are virtually invisible from the right side of the fabric. This blind hem stitch is designed for use with woven (non-stretch) fabrics. For information how to sew a blind hem, see this video.</p>
57	BLIND HEM STITCH	Blind Stitch Applique		<p>The blind hem stitch can be used to attach appliques. The applique fabric edge is turned under and pressed, then secured to the main fabric with fusible web or temporary fabric spray adhesive. Select the blind hem stitch. For machines with adjustable stitch length and stitch width, set the stitch width to about 1.0 - 1.5mm, and the stitch length to a medium setting. Sew around the applique so the "straight" part of the stitch falls just outside the applique edge, and the longer part of the stitch sews just over the fabric fold. Use thread in a color that matches as closely as possible to the applique fabric color for a nearly invisible stitch.</p>






## English

58	BLIND HEM STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
59	BLIND HEM STITCH	Couching		Create interesting surface embellishment using the blind hem stitch to sew over lightweight cords, yarns or trims. For machines with adjustable stitch width, choose a stitch width setting that is wide enough to cover the trim, without actually stitching into the trim. It can also be helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear area in front of the needle as you sew. Use a slow speed and take your time for maximum control.
60	STRETCH BLIND HEM STITCH	Stretch Hems		Use a Blind Hem Foot (additional accessory for some machine models) in conjunction with your machine's blind hem stitch to sew hems that are virtually invisible from the right side of the fabric. This blind hem stitch is designed for use with stretch fabrics like t-shirts, jersey and more. For information on how to sew a blind hem, see this video.
61	STRETCH BLIND HEM STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using. Learn more about needles on the SINGER website.
62	PICOT HEM STITCH	Picot Hems		A picot hem provides a small, scalloped edge, especially for fabrics such as tricot or light jersey knits. Fold the hem allowance under, then stitch along the fold so that the "straight" part of the stitch sews within the hem, and the "point" sews off the edge of the hem's fold. The result is a scalloped edge. For machines with adjustable stitch length and stitch width, set the stitch width and stitch length based on how you want the hem to look, and practice first on a scrap fabric.





## English

63	PICOT HEM STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
64	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
65	DECORATIVE STITCH	Couching		<p>Sew over ribbons, lightweight yarns or cords to embellish fabrics. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area. Use a tear-away stabilizer underneath as you sew to help prevent fabric puckering.</p>
66	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>






## English

67	DECORATIVE STITCH	Couching		Use this decorative stitch, sometimes called a Triple Domino stitch, along with a Cording Foot to add interesting surface dimension to your projects by stitching over cords or thin yarns. The Cording Foot (additional accessory for some machine models) has grooves on top that help guide thin yarns or cords as you stitch over them. The stitch "catches" the cords to secure them to the fabric surface. Use a tear-away stabilizer underneath as you sew to help prevent fabric puckering.
68	STRAIGHT STRETCH STITCH	Stretch Seams		This stitch can be used to reinforce seams of stretch fabrics. The stitch is stronger than a regular straight stitch because it sews the same stitch three times - forward, backward and forward again. Because the stitch stretches, it's a good choice for seams on medium to heavy weight stretch fabrics. The stitch will stretch with the fabric when the fabric is stretched. Use a Ball Point needle to help prevent skipped stitches on stretch fabrics. Learn more about needles on the SINGER website.
69	STRAIGHT STRETCH STITCH	Heirloom Stitching		This stitch can be used to create a delicate heirloom look for fabrics such as organza, organdy and batiste. Use a SINGER Wing Needle (additional accessory), which creates little holes each time it makes a stitch. Use lightweight thread in the needle and bobbin, as regular all-purpose thread is too thick and will "fill up" the holes. Learn more about needles on the SINGER website.
70	STRAIGHT STRETCH STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
71	STRAIGHT STRETCH STITCH	Reinforced Seams		This stitch can be used to reinforce seams of heavy woven fabrics, such as denim, canvas, and duck cloth. The stitch is stronger than a regular straight stitch because it sews the same stitch three times - forward, backward and forward again. Use a SINGER size 16 or size 18 needle for sewing these types of heavyweight fabrics. More information about needles can be found on the SINGER website.







## English








72	REINFORCED ZIGZAG STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
73	REINFORCED ZIGZAG STITCH	Couching		<p>Use the Reinforced Zigzag Stitch to add interesting surface dimension to your projects by stitching over narrow ribbons or cords. It is helpful to use an Open Toe Foot (additional accessory for some machine models). As you sew, the stitch "catches" the cord to secure to the fabric surface. Use a tear-away stabilizer underneath as you sew to help prevent the dense stitches from puckering the fabric.</p>
74	HONEYCOMB STITCH	Elastic Insertion		<p>Insert elastic to your projects easily by sewing over the elastic with the Honeycomb stitch. For elastic that is 1/4" - 3/8" wide, place the elastic through the opening of the All-Purpose Foot. This will help keep the elastic from slipping from left to right as you sew. Hold the elastic from in front and in back of the presser foot, stretching the elastic as you do so.</p>
75	HONEYCOMB STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>






English				
76	HONEYCOMB STITCH	Smocking		Sew the Honeycomb Stitch over gathered fabric to create smocking, often seen in children's clothing and vintage apparel. This technique works best with lightweight woven fabrics, like batiste or voile. Start by sewing several rows of basting stitches: sew 1 row, then a second row 1/8" inch from the first. Skip 1/2" and repeat, continuing for the amount needed for your project. Gather the basting threads. Place the gathered piece over a fabric interfacing or piece of organza. To sew the Honeycomb stitch, use a 30wt cotton in the needle, which will provide a hand-sewn look, and stitch over the basted rows.
77	HONEYCOMB STITCH	Couching		Use this decorative stitch, sometimes called a Triple Domino stitch, along with a Cording Foot to add interesting surface dimension to your projects. The Cording Foot (additional accessory for some machine models) has grooves on top that help guide thin yarns or cords as you stitch over them. The stitch "catches" the cords to secure them to the fabric surface. Use a tear-away stabilizer underneath as you sew to help prevent fabric puckering.
78	HONEYCOMB STITCH	Hemming		Use the Honeycomb Stitch to create sportswear-style hems on stretch knit fabrics. The stitch is flexible and will stretch when the fabric stretches. Turn up the hem allowance and pin the hem in place. Stitch from the top side of the garment, catching the raw edge of the hem on the back side as you sew. Use a polyester or all-purpose thread. Use a Ball Point Needle when sewing stretch fabrics, to prevent skipped stitches. Learn more about needles on the SINGER website.
79	DOUBLE OVERLOCK STITCH	Seam with Seam Finish		The Double Overlock Stitch is a stretch stitch, but it can be used on stretch fabrics and non-stretch fabrics (wovens) as well. It sews a seam and a seam finish, all at the same time. There is a reinforcing stitch at the right side, further strengthening the stitch. Sew the stitch with the left side on the seam line of your project. Trim excess seam allowance when finished sewing.
80	DOUBLE OVERLOCK STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.

## English






81	DOUBLE OVERLOCK STITCH	Couching		Use the Double Overlock Stitch to add interesting surface dimension to your projects by stitching over thin yarns or cords.. The Open Toe Foot (additional accessory for some machine models) can be helpful because it provides a clear view of the sewing area. Use a tear-away stabilizer underneath as you sew to help prevent fabric from puckering.
82	DOUBLE OVERLOCK STITCH	Hemming		Use the Double Overlock Stitch to create sportswear-style hems on stretch knit fabrics. The stitch is flexible and will stretch when the fabric stretches. Turn up the hem allowance and pin the hem in place. Stitch from the top side of the garment, catching the raw edge of the hem on the back side as you sew. Use a polyester or all-purpose thread. Use a Ball Point Needle when sewing stretch fabrics, to prevent skipped stitches. Learn more about needles on the SINGER website.
83	DECORATIVE STITCH	Elastic Insertion		Insert elastic into your projects easily by sewing over the elastic with this stitch, sometimes called the Feather Stitch. For elastic that is 1/4" - 3/8" wide, place the elastic through the opening of the All-Purpose Foot. This will help keep the elastic from slipping from left to right as you sew. Hold the elastic from in front and in back of the presser foot, stretching the elastic as you do so.
84	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models)for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
85	DECORATIVE STITCH	Crazy Patch Quilting		Use this decorative stitch to embellish seams on quilt tops. For a bold appearance, try 30wt or 12wt cotton in the needle. At the end of a row of stitching, instead of reverse stitching, bring thread tails to the back side using a hand sewing needle, then tie to secure.
86	OVERLOCK STITCH	Seam with Seam Finish		This Overlock Stitch is a stretch stitch, but it can be used on stretch fabrics and non-stretch fabrics (wovens) as well. It sews a seam and a seam finish, all at the same time. Sew the stitch with the left side on the seam line of your project. Trim excess seam allowance when finished sewing.








English				
87	OVERLOCK STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
88	BARTACK BUTTONHOLE	Buttonholes		Machine buttonholes are quick and easy to sew. Check your machine manual for details on how to create buttonholes for your specific machine model. Tip: If your machine model doesn't have an automatic tie-off, use a hand sewing needle to bring the thread tails to the back side of your project, then tie them to secure so that the buttonhole stitches don't unravel.
89	BARTACK BUTTONHOLE	Decorative Stitching		Try sewing the buttonhole stitch as a decorative stitch. Sew several on the fabric as desired. Don't cut them open - simply use them as a way to add surface embellishment to your fabric!
90	BARTACK BUTTONHOLE	Decorative Eyelets		Use your machine's buttonhole function to create small "eyelets". By making very short buttonholes, you can create openings through which you can weave ribbons or cords, for decorative embellishment.
91	STRETCH TRICOT STITCH	Stretch Seams		This stitch can be used to sew seams on stretch fabrics. It's a good choice for seams on lightweight to medium weight stretch fabrics. The stitch will stretch with the fabric when the fabric is stretched. Use a Ball Point Needle to prevent skipped stitches on the stretch fabric. Learn more about needles on the SINGER website.
92	STRETCH TRICOT STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
93	STRETCH TRICOT STITCH	Stretch Hems		Use the Stretch Tricot Stitch to sew hems on stretch knit fabrics. The stitch is flexible and will stretch when the fabric stretches. Turn up the hem allowance and pin the hem in place. Stitch from the top side of the garment, making sure to catch the hem on the back side as you sew. Use a polyester or all-purpose thread. Use a Ball Point Needle when sewing stretch fabrics, to prevent skipped stitches. Learn more about needles on the SINGER website.





## English






94	HAND LOOK QUILTING STITCH	Echo Quilting		<p>Echo quilting, also called 'outline quilting', is done by following around the shape of an applique, a design printed in the fabric, or even an embroidery. The hand-look quilting stitch looks like row of stitches sewn by hand. Thread the bobbin in a color you want for the stitches which will actually appear on the top side of your quilt layers. Thread the needle with a thread color that blends with the top fabric. Select the hand-look quilting stitch and sew a sample first. It may be necessary to increase the upper thread tension to help "pull" the bobbin thread up a bit more. Adjust stitch length as desired. For echo quilting, sew around a the design, creating an "outline" around it. Continue sewing additional rows as desired. It is helpful to use an Open Toe Foot (additional accessory for some machine models) for a clear view of the sewing area.</p>
95	HAND LOOK QUILTING STITCH	Sashiko		<p>The look of sashiko stitching can be created using the hand-look quilting stitch, which looks like a row of stitches sewn by hand. Thread the bobbin in a color that you want for the stitches which will actually appear on the top side of your project. Thread the needle with a thread color that matches or blends very well with the top fabric. Select the stitch and try sewing a sample first. It may be necessary to increase the upper thread tension to help "pull" the bobbin thread up a bit more. Adjust stitch length as desired for the look of your project. For creating a sashiko pattern, try a removable fabric marker to draw stitching guidelines on the fabric. It may be helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area.</p>
96	HAND LOOK QUILTING STITCH	Decorative Stitching		<p>The hand-look quilting stitch looks like a row of small stitches sewn by hand. Thread the bobbin in a color that you want for the stitches which will actually appear on the top side of your project. Thread the needle with a thread color that matches or blends very well with the top fabric. Select the stitch and try sewing a sample first. It may be necessary to increase the upper thread tension to help "pull" the bobbin thread up a bit more. Adjust stitch length as desired for the look of your project. It may be helpful to use an Even Feed / Walking Foot (additional accessory for some machine models) to prevent layers from shifting.</p>

**English**









97	HAND LOOK QUILTING STITCH	Quilting		<p>The hand-look quilting stitch looks like a row of small stitches sewn by hand. Thread the bobbin in a color that you want for the stitches which will actually appear on the top side of your project. Thread the needle with a thread color that matches or blends very well with the top fabric. Select the stitch and try sewing a sample first. It may be necessary to increase the upper thread tension to help "pull" the bobbin thread up a bit more. Adjust stitch length as desired for the look of your project. For quilting rows, try using a removable fabric marker to draw stitching guidelines. It may be helpful to use an Even Feed / Walking Foot (additional accessory for some machine models) to prevent fabric layers from shifting.</p>
98	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
99	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
100	DECORATIVE STITCH	Scallop Hems		<p>Use this decorative stitch to add a scalloped hem to projects like table linens, children's clothing, and much more. Set the stitch width to its widest setting and the stitch length as desired. Place two lightweight fabrics together, right sides facing. Sew the stitch near the bottom of the hem. When finished sewing, use a fine point scissor to trim the seam allowance into the "corners" of the scallops. Turn the hem right side out and press.</p>
101	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>








English				
102	DECORATIVE STITCH	Couching		Sew this stitch over light weight ribbon or trim to add surface dimension to your fabrics. Use an Open Toe Foot or Satin Stitch Foot (additional accessory for some machine models) to make it easier to sew over the thickness of the stitch and trim. Use a tear-away stabilizer underneath as you sew to help prevent fabric puckering.
103	OVERLOCK STITCH	Seam with Seam Finish		This Overlock Stitch is a stretch stitch, but it can be used on stretch fabrics and non-stretch fabrics (wovens) as well. It sews a seam and a seam finish, all at the same time. Sew the stitch with the left side on the seam line of your project. Trim excess seam allowance when finished sewing.
104	OVERLOCK STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
105	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
106	DECORATIVE STITCH	Attaching Appliques		Use this stitch to sew around appliques, to secure them to the main fabric. Set the stitch length and stitch width to be proportionate to the size of the applique and look you want.
107	DECORATIVE STITCH	Quilt Binding		This decorative stitch can be used to embellish a quilt binding. Allow the left side of the stitch to sew in the "ditch" between the main quilt and the binding. The horizontal stitches will sew into the quilt binding, adding a decorative touch.
108	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.






English				
109	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
110	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
111	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
112	DECORATIVE STITCH	Edge Joining		Two fabrics can be joined together using this decorative stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (additional accessory for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. If your machine has adjustable stitch length and width, select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle (additional accessory for some machine models) for a more bold appearance to the stitches.

English				
113	DECORATIVE STITCH	Attaching Trim		Use this decorative stitch to attach ribbons and trims. It's an easy way to embellish projects. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area. For machines with adjustable stitch length and stitch width, set the stitch length and stitch width according to your ribbon width and the look you want for your project.
114	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
115	DECORATIVE STITCH	Edge Joining		Two fabrics can be joined together using this decorative stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (additional accessory for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. For machines with adjustable stitch length and stitch width, select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle (additional accessory) for a more bold appearance to the stitches.
116	DECORATIVE STITCH	Attaching Trim		Use this decorative stitch to attach ribbons and trims. It's an easy way to embellish projects. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area. For machines with adjustable stitch length and stitch width, set the stitch length and stitch width according to your ribbon width and the look you want for your project.
117	SLANT OVEREDGE STITCH	Seam with Seam Finish		This Slant Overedge Stitch is a stretch stitch, but it can be used on stretch fabrics and non-stretch fabrics (wovens) as well. It sews a seam and a seam finish, all at the same time. Sew with the left side of the stitch on the seam line of your project. Trim excess seam allowance when finished sewing.






English				
118	SLANT OVEREDGE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
119	ROUND END BARTACK BUTTONHOLE	Buttonhole for Light to Medium Weight Fabrics		This buttonhole is a good choice for light to medium weight fabrics. Use a lightweight tear-away or wash-away stabilizer under the fabric to help prevent the dense stitches from puckering the fabric.
120	ROUND END BUTTONHOLE	Buttonhole for Light to Medium Weight Fabrics		This buttonhole is a good choice for light to medium weight fabrics. Use a lightweight tear-away or wash-away stabilizer under the fabric to help prevent the dense stitches from puckering the fabric.
121	KEYHOLE BUTTONHOLE	Buttonholes for Tailored Jackets, Coats and Outerwear		This buttonhole is a good choice for tailored jackets, coats and outerwear. It has a larger opening at one end, which helps accommodate the larger size buttons often used on these types of garments. Use a tear-away stabilizer underneath to help prevent the fabric from puckering.
122	HEIRLOOM BUTTONHOLE	Handlook Buttonhole for Finer Fabrics		Use this buttonhole for finer fabrics. It is helpful to use a light tear-away or wash-away stabilizer underneath to help prevent the fabric from puckering. When sewing finer fabrics, be sure to use a finer sized needle as well. Learn more about needles on the SINGER website.
123	KEYHOLE BUTTONHOLE WITH POINTED END	Buttonhole with Tapered End for Tailored Garments		This buttonhole is a good choice for tailored jackets, coats and outerwear. It has a larger opening at one end, which helps accommodate the larger size buttons often used on these types of garments. Use a tear-away stabilizer underneath to help prevent the fabric from puckering.
124	ROUNDED BUTTONHOLE	Handlook Buttonhole for Finer Fabrics		Use this buttonhole for finer fabrics. It is helpful to use a light tear-away or wash-away stabilizer underneath to help prevent the fabric from puckering. When sewing finer fabrics, be sure to use a finer sized needle as well. Learn more about needles on the SINGER website.
125	REINFORCED STRETCH BUTTONHOLE	Stretch Buttonhole for Heavy Weight Knit Fabrics		This style of buttonhole is designed for heavyweight knit (stretch) fabrics. The buttonhole has a small amount of stretch, making it a good choice for these fabrics. Use a light tear-away stabilizer underneath to stabilize the fabric as you sew, to eliminate fabric puckers or distortion. Use a Ball Point Needle with stretch fabrics, to prevent skipped stitches. Learn more about needles on the SINGER website.




English				
126	STRETCH BUTTONHOLE	Stretch Buttonhole for Light to Medium Weight Knit Fabrics		This style of buttonhole is designed for light to medium weight knit (stretch) fabrics. The buttonhole has a small amount of stretch, making it a good choice for these fabrics. Use a light tear-away stabilizer underneath to stabilize the fabric as you sew, to eliminate fabric puckers or distortion. Use a Ball Point Needle with stretch fabrics, to prevent skipped stitches. Learn more about needles on the SINGER website.
127	BARTACK STITCH	Attaching Belt Loops		The Bartack Stitch can be used to attach belt loops. Use a needle that is strong enough to sew through the thickness of the bartack and main fabric. Learn more about needles on the SINGER website.
128	BARTACK STITCH	Securing Stress Points		The Bartack Stitch can be used to secure the corners of pockets, stress points on jeans, zippers and more.
129	BARTACK STITCH	Decorative Stitching		Use the Bartack Stitch as a decorative stitch. Sew several on the fabric to create interesting surface design. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using. Learn more about needles on the SINGER website.
130	BARTACK STITCH	Attaching Ribbons		Attach ribbons or trims to a base fabric for a fun embellishment. Cut a length of ribbon, sew the Bartack Stitch over it to secure it in place on the main fabric. It is helpful to place a small scrap of stabilizer underneath the fabric. When the bartack has been sewn, tie the ribbon into a bow to finish.
131	DARNING STITCH	Darning		Darning is the process of repairing a hole, rip or tear with machine stitching. The Buttonhole Foot can be used to easily sew a Darning Stitch to repair small holes, rip and tears. See the manual for your machine model for more information. Use a thread in a color that matches or blends well with the fabric to be repaired. Place a small piece of fabric under the hole or tear, which will provide added stability to the area being repaired.
132	EYELET STITCH	Creating Eyelets		Eyelet Stitches can be used a number of ways, such as openings for ribbons or laces, embellishing around appliques and embroideries, heirloom sewing and more. It is helpful to use a light tear-away or wash-away stabilizer underneath to help prevent the fabric from puckering. Experiment with various threads such as rayon thread, all-purpose thread, and even 30wt cotton to find the look you want for your project.

English				
133	EYELET STITCH	Decorative Stitching		Create interesting texture and surface embellishment by sewing the Eyelet Stitch randomly on your fabric. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using. Learn more about needles on the SINGER website.
134	BUTTON SEWING STITCH	Attaching Buttons		The Button Sewing Stitch is used along with a Button Sewing Foot (additional accessory for some machine models) to easily attach buttons by machine. The foot holds the button in place, while still providing a clear view of the stitching area. The rubber grips on the front of the foot keep the button from slipping out of place. See this video for information on sewing buttons by machine.
135	BUTTON SEWING STITCH	Attaching Trims		Attach ribbons or trims to a base fabric for a fun embellishment. Disengage the machine's feed teeth (see your machine's manual). Cut a length of ribbon, then sew the Button Sewing Stitch over it to secure it in place on the main fabric. It is helpful to place a small scrap of stabilizer underneath the fabric. When the stitch has been sewn, bring thread tails to the back side of the fabric with a hand sewing needle, then tie the ribbon into a bow to finish.
136	BUTTON SEWING STITCH	Quilt Tacking		The Button Sewing Stitch can be used to attach quilt layers together. Disengage the machine's feed teeth (see your machine's manual). Attach the Button Sewing Foot or Open Toe Foot (additional accessory for some machine models). Place the quilt layers underneath the foot, lower the presser foot lifter and sew 8-10 stitches to tack the layers together. Stitches can be easily removed with a seam ripper after the project has been quilted.
137	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.




## English

138	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
139	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
140	DECORATIVE STITCH	Scallop Hems		<p>Use this decorative stitch to add a scalloped hem to projects like table linens, children's clothing, and much more. Select the scallop decorative stitch. For machines with adjustable stitch width and stitch length, set the stitch width to its widest setting and the stitch length to a short setting so that you don't see fabric between the stitches. Use a Satin Stitch Foot (additional accessory for some machine models), which will allow the dense stitching to pass freely underneath the foot. Use a wash-away or very light tear-away stabilizer under the fabric. Sew the stitch, then remove the stabilizer. Use a fine point scissor to trim away excess fabric, leaving a scallop hem at the edge.</p>




## English

141	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
142	DECORATIVE STITCH	Attaching Trims		Use this decorative stitch to attach ribbons and trims. It's an easy way to embellish projects. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area. For machines with adjustable stitch length and stitch width, set the stitch length and stitch width according to the look you want for your project.
143	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.




## English

144	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
145	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
146	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>

## English




147	DECORATIVE STITCH	Couching		<p>Use this decorative stitch, sometimes called a Domino stitch, along with a Cording Foot to add interesting surface dimension to your projects. The Cording Foot (additional accessory for some machine models) has grooves on top that help guide thin yarns or cords as you stitch over them. The stitch "catches" the cords to secure them to the fabric surface. Use a tear-away stabilizer underneath as you sew to help prevent fabric puckering. See this video for a demonstration of the Cording Foot.</p>
148	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
149	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>

## English




150	DECORATIVE STITCH	Scallop Hems		<p>Use this decorative stitch to add a scalloped hem to projects like table linens, children's clothing, and much more. Select the scallop decorative stitch. If your machine has adjustable stitch length and stitch width, set the stitch width to its widest setting and the stitch length to a short setting so that you don't see fabric between the stitches. Use a Satin Stitch Foot (additional accessory for some machine models), which will allow the dense stitching to pass freely underneath the foot. Use a wash-away or very light tear-away stabilizer under the fabric. Sew the stitch, then remove the stabilizer. Use a fine point scissor to trim away excess fabric, leaving a scallop hem at the edge.</p>
151	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
152	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>






## English




153	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
154	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
155	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>

**English**




156	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
157	DECORATIVE STITCH	Scallop Hems		Use this decorative stitch to add a scalloped hem to projects like table linens, children's clothing, and much more. Select the scallop decorative stitch. If your machine has adjustable stitch length and stitch width, set the stitch width to its widest setting and the stitch length to a short setting so that you don't see fabric between the stitches. Use a Satin Stitch Foot (additional accessory for some machine models), which will allow the dense stitching to pass freely underneath the foot. Use a wash-away or very light tear-away stabilizer under the fabric. Sew the stitch, then remove the stabilizer. Use a fine point scissor to trim away excess fabric, leaving a scallop hem at the edge.
158	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.

## English




159	DECORATIVE STITCH	Scallop Hems		<p>Use this decorative stitch to add a scalloped hem to projects like table linens, children's clothing, and much more. Select the scallop decorative stitch. If your machine has adjustable stitch length and stitch width, set the stitch width to its widest setting and the stitch length to a short setting so that you don't see fabric between the stitches. Use a Satin Stitch Foot (additional accessory for some machine models), which will allow the dense stitching to pass freely underneath the foot. Use a wash-away or very light tear-away stabilizer under the fabric. Sew the stitch, then remove the stabilizer. Use a fine point scissor to trim away excess fabric, leaving a scallop hem at the edge.</p>
160	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
161	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>

English				
162	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
163	DECORATIVE STITCH	Couching		Use this decorative stitch, along with a Cording Foot, to add interesting surface dimension to your projects. The Cording Foot (additional accessory for some machine models) has grooves on top that help guide a thin yarn or cord as you stitch over it. The stitch "catches" the cord to secure to the fabric surface. Use a tear-away stabilizer underneath as you sew to help prevent fabric puckering.
164	DECORATIVE STITCH	Edge Joining		Two fabrics can be joined together using this decorative stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (additional accessory for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. Select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle for a more bold appearance to the stitches.





**English**

165	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
166	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
167	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>





## English

168	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
169	DECORATIVE STITCH	Smocking		Sew this cross-stitch pattern over gathered fabric to create smocking, often seen in children's clothing and even vintage apparel. This technique works best with lightweight woven fabrics, like batiste or voile. Start by sewing several rows of basting stitches - sew 1 row, then a second row 1/8" inch from the first. Skip 1/2" and repeat, continuing to sew basting stitch rows for the amount needed for your project. Gather the basting threads. Place the gathered piece over a fabric interfacing or piece of organza. To sew the cross-stitch pattern, use a 30wt cotton in the needle, which will provide a hand-look, and stitch over the basted rows.
170	DECORATIVE STITCH	Couching		Use this decorative stitch, along with a Cording Foot, to add interesting surface dimension to your projects. The Cording Foot (additional accessory for some machine models) has grooves on top that help guide a thin yarn or cord as you stitch over it. The stitch "catches" the cord to secure to the fabric surface. Use a tear-away stabilizer underneath as you sew to help prevent fabric puckering.
171	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.

## English



172	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
173	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
174	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
175	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.

## English




176	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
177	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
178	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
179	DECORATIVE STITCH	Applique		This decorative stitch can be used to sew appliques. It will take some experimenting on scrap fabric to find the exact settings you want for your applique. Set the width at a medium setting to start, and adjust from there. Use an Open Toe Foot (additional accessory for some machine models) which will provide a clear view of the sewing area. The right side of the stitch should hug the outside edge of the applique, and the horizontal stitches should then stitch into the applique itself.








## English






180	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
181	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
182	DECORATIVE STITCH	Applique		This decorative stitch can be used to sew appliques. It will take some experimenting on scrap fabric to find the exact settings you want for your applique. Set the width at a medium setting to start, and adjust from there. Use an Open Toe Foot (additional accessory for some machine models) which can be helpful because it provides a clear view of the sewing area. The right side of the stitch should hug the outside edge of the applique, and the horizontal stitches should then stitch into the applique itself.
183	DECORATIVE STITCH	Heirloom Sewing		This stitch is commonly used for heirloom sewing and vintage style projects. These stitches look best when sewn on lightweight fabrics such as organdy, organza, or batiste. It is helpful to prepare the fabric with fabric spray starch and press it so it has more "body", as the stitch is dense and also usually sewn on a single layer of fabric. Use a SINGER Hemstitching Needle (additional accessory), which helps create small "holes" in the fabric as you sew. Use a lightweight thread in the needle and bobbin, as all-purpose thread will be too thick and the holes created by the wing needle won't show as well. An Open Toe Foot (additional accessory for some machine models) can be helpful because it provides a clear view as you sew. Press again when finished.

## English




184	ENTREDEUX STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
185	ENTREDEUX STITCH	Creating Entredeux		<p>Entredeux stitches are mainly used for heirloom sewing and vintage style projects. These stitches look best when sewn on lightweight fabrics such as organdy, organza, or batiste. It is helpful to prepare the fabric with fabric spray starch and press it so it has more "body", as the Entredeux Stitch is dense and also usually sewn on a single layer of fabric. Use a SINGER Hemstitching Needle (additional accessory), which helps create small "holes" in the fabric as you sew. Use a lightweight thread in the needle and bobbin, as all-purpose thread will be too thick and the holes created by the wing needle won't show as well. An Open Toe Foot (additional accessory for some machine models) can also be helpful because it provides a clear view as you sew. Press again when finished.</p>
186	ENTREDEUX STITCH	Joining Fabric and Lace		<p>Heirloom sewing incorporates several different techniques, and one is joining fabric and lace. This works best on fine, lightweight fabrics like batiste, organdy and organza. Thread the machine with lightweight thread and a SINGER Hemstitching Needle (additional accessory). Set the machine for the Entredeux Stitch. It can be helpful to use an Open Toe Foot (additional accessory for some machine models) so that the area in front of the needle is unobstructed. Fold the edge of the fabric under, then place the fabric fold next to the flat edge of the lace. Sew the main part of the stitch on the fabric, allowing the right movement of the needle to catch the heading of the lace. When finished, use a fine scissor to trim away the excess fabric allowance.</p>

## English





187	ENTREDEUX STITCH	Applique		This decorative stitch can be used to sew appliques. It will take some experimenting on scrap fabric to find the exact settings you want for your applique. Set the width at a medium setting to start, and adjust from there. Use an Open Toe Foot (additional accessory for some machine models) which can be helpful because it provides a clear view of the sewing area. The center of the stitch should hug the outside edge of the applique, the left side of the stitch sews on the applique, and the right side of the stitch sew onto the main fabric.
188	ENTREDEUX STITCH	Quilt Binding		This decorative stitch can be used to embellish a quilt binding. Allow the center of the stitch to sew in the "ditch" between the main quilt and the binding. The horizontal stitches will sew into the quilt binding on the right and into the main quilt on the left, adding a decorative touch.
189	DECORATIVE STITCH	Applique		This decorative stitch can be used to sew appliques. It will take some experimenting on scrap fabric to find the exact settings you want for your applique. Set the width at a medium setting to start, and adjust from there. Use an Open Toe Foot (additional accessory for some machine models) which can be helpful because it provides a clear view of the sewing area. The center of the stitch should hug the outside edge of the applique, the left side of the stitch sews on the applique, and the right side of the stitch sew onto the main fabric.
190	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
191	DECORATIVE STITCH	Quilting		Use this decorative stitch to embellish seams on quilt tops. For a bold appearance, try 30wt or 12wt cotton in the needle. At the end of a row of stitching, instead of reverse stitching, bring thread tails to the back side using a hand sewing needle, then tie to secure. An Open Toe Foot (additional accessory for some machine models) can be helpful because it provides a clear view of the stitch area.

English				
192	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
193	DECORATIVE STITCH	Edge Joining		Two fabric edges can be joined together using this decorative stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (additional accessory for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. Select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle (additional accessory) for a more bold appearance to the stitches.
194	DECORATIVE STITCH	Crazy Patch Quilting		Use this decorative stitch to embellish seams on quilt tops. For a bold appearance, try 30wt or 12wt cotton in the needle. At the end of a row of stitching, instead of reverse stitching, bring thread tails to the back side using a hand sewing needle, then tie to secure. An Open Toe Foot (additional accessory for some machine models) can also be helpful because it provides a clear view of the stitch area.
195	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
196	DECORATIVE STITCH	Applique		This decorative stitch can be used to sew appliques. It will take some experimenting on scrap fabric to find the exact settings you want for your applique. Set the width at a medium setting to start, and adjust from there. Use an Open Toe Foot (additional accessory for some machine models) which can be helpful because it provides a clear view of the sewing area. The right side of the stitch should hug the outside edge of the applique, and the horizontal stitches should then stitch into the applique itself.




## English

197	DECORATIVE STITCH	Edge Joining		<p>Two fabric edges can be joined together using this decorative stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (additional accessory for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. Select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle (additional accessory) for a more bold appearance to the stitches.</p>
198	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
199	DECORATIVE STITCH	Crazy Patch Quilting		<p>Use this decorative stitch to embellish seams on quilt tops. For a bold appearance, try 30wt or 12wt cotton in the needle. At the end of a row of stitching, instead of reverse stitching, bring thread tails to the back side using a hand sewing needle, then tie to secure. An Open Toe Foot (additional accessory for some machine models) can be helpful as well because it provides a clear view of the stitch area.</p>





## English

200	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. For machine models with adjustable stitch length and/or stitch width, try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
201	DECORATIVE STITCH	Couching		<p>Use this decorative stitch, along with a Cording Foot, to add interesting surface dimension to your projects. The Cording Foot (additional accessory for some machine models) has a groove on top that helps guide a thin yarn or cord as you stitch over it. The stitch "catches" the cord to secure to the fabric surface. Use a tear-away stabilizer underneath as you sew to help prevent fabric puckering. See a demonstration of the Cording Foot in this video.</p>
202	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
203	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>






## English






204	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
205	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
206	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>




## English

207	DECORATIVE STITCH	Edge Joining		<p>Two fabrics can be joined together using this decorative stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (optional for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. Select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle for a more bold appearance to the stitches.</p>
208	DECORATIVE STITCH	Applique		<p>This decorative stitch can be used to sew appliques. It will take some experimenting on scrap fabric to find the exact settings you want for your applique. Set the width at a medium setting to start, and adjust from there. Use an Open Toe Foot (additional accessory for some machine models) which can be helpful because it provides a clear view of the sewing area. The center of the stitch should hug the outside edge of the applique, the left side of the stitch sews on the applique, and the right side of the stitch sews onto the main fabric.</p>
209	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
210	DECORATIVE STITCH	Applique		<p>This decorative stitch can be used to sew appliques. It will take some experimenting on scrap fabric to find the exact settings you want for your applique. Set the width at a medium setting to start, and adjust from there. Use an Open Toe Foot (additional accessory for some machine models) which can be helpful because it provides a clear view of the sewing area. The right side of the stitch should hug the outside edge of the applique, and the horizontal stitches should then stitch into the applique itself.</p>






English				
211	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
212	DECORATIVE STITCH	Quilting		This decorative stitch can be sewn in parallel rows to help create loft in the layers of quilt blocks. The thread is usually in a color that matches or blends well with the fabric, so that just the quilt texture is noticeable when finished stitching. Experiment with various stitch length and stitch width settings to achieve the look you want for your project.
213	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
214	DECORATIVE STITCH	Quilting		This decorative stitch resembles free-motion stipple quilting. Sew several rows close together to create a stipple quilting look. The stitch is 7mm wide, so this technique is best for small quilted areas, rather than full sized quilts. Select a thread color that matches or blends well with the fabric so that just the quilt texture is noticeable when stitching is finished.
215	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.





English				
216	DECORATIVE STITCH	Quilting		This decorative stitch can be sewn in parallel rows to help create loft in the layers of quilt blocks. The thread is usually in a color that matches or blends well with the fabric, so that just the quilt texture is noticeable when finished stitching. Experiment with various stitch length and stitch width settings to achieve the look you want for your project.
217	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
218	DECORATIVE STITCH	Attaching Trims		Use this decorative stitch to attach ribbons and trims. It's an easy way to embellish projects. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area. Set the stitch length and stitch width according to the look you want for your project. See a demonstration of the Open Toe Foot in this video.
219	DECORATIVE STITCH	Crazy Patch Quilting		Use this decorative stitch to embellish seams on quilt tops. For a bold appearance, try 30wt or 12wt cotton in the needle. At the end of a row of stitching, instead of reverse stitching, bring thread tails to the back side using a hand sewing needle, then tie to secure. An Open Toe Foot (additional accessory for some machine models) can be helpful as well because it provides a clear view of the stitch area.
220	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, and even metallic thread. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.

English				
221	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
222	DECORATIVE STITCH	Heirloom Stitching		This decorative stitch can be used for heirloom sewing and vintage style projects. These stitches look best when sewn on lightweight fabrics such as organdy, organza, or batiste. It is helpful to prepare the fabric with fabric spray starch and press it so it has more "body", as the stitch is dense and also usually sewn on a single layer of fabric. Use a SINGER Hemstitching Needle (additional accessory), which helps create small "holes" in the fabric as you sew. Use a lightweight thread in the needle and bobbin, as all-purpose thread will be too thick and the holes created by the wing needle won't show as well. An Open Toe Foot (additional accessory for some machine models) can also be helpful because it provides a clear view as you sew.
223	DECORATIVE STITCH	Smocking		Sew this stitch pattern over gathered fabric to create smocking, often seen in children's clothing and even vintage apparel. This technique works best with lightweight woven fabrics, like batiste or voile. Start by sewing several rows of basting stitches - sew 1 row, then a second row 1/8" inch from the first. Skip 1/2" and repeat, continuing for the amount of basting rows needed for your project. Gather the basting threads. Place the gathered piece over a fabric interfacing or piece of organza. To sew the cross-stitch pattern, use a 30wt cotton in the needle, which will provide a hand-sewn look, and stitch over the basted rows.






**English**

224	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
225	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
226	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>





## English

227	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
228	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
229	DECORATIVE STITCH	Attaching Trims		<p>Use this decorative stitch to attach ribbons and trims. It's an easy way to embellish projects. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area. Set the stitch length and stitch width according to the look you want for your project. See a demonstration of the Open Toe Foot in this video.</p>
230	DECORATIVE STITCH	Edge Joining		<p>Two fabric edges can be joined together using this decorative stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (additional accessory for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. Select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle for a more bold appearance to the stitches.</p>





## English

231	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
232	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
233	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
234	DECORATIVE STITCH	Quilting		This decorative stitch can be sewn in parallel rows to help create loft in the layers of quilt blocks. The thread is usually in a color that matches or blends well with the fabric, so that just the quilt texture is noticeable when finished stitching. Experiment with various stitch length and stitch width settings to achieve the look you want for your project.
235	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.

## English





236	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
237	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
238	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
239	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>

## English






240	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
241	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
242	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
243	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>







## English

244	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
245	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
246	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.</p>
247	DECORATIVE STITCH	Couching		<p>Use this decorative stitch, along with a Cording Foot, to add interesting surface dimension to your projects. The Cording Foot (additional accessory for some machine models) has grooves on top that help guide a thin yarn or cord as you stitch over it. The stitch "catches" the cord(s) to secure to the fabric surface. Use a tear-away stabilizer underneath as you sew to help prevent fabric puckering.</p>





## English

248	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
249	DECORATIVE STITCH	Attaching Trim		Use this decorative stitch to attach ribbons and trims. It's an easy way to embellish projects. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area. Set the stitch length and stitch width according to the look you want for your project.
250	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
251	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
252	DECORATIVE STITCH	Sewing Flat Seams		Some fabrics such as vinyl, neoprene, cork and others are somewhat stiff and may be difficult to work with when sewing seams. In these case, the fabrics can be overlapped and then sewn with this decorative stitch. Doing this eliminates excess bulk and provides a smooth seam. It may be helpful to use a Non-stick Foot (additional accessory for some machine models) for sewing fabrics like vinyl.






## English

253	DECORATIVE STITCH	Attaching Trims		Use this decorative stitch to attach ribbons and trims. It's an easy way to embellish projects. It is helpful to use an Open Toe Foot (additional accessory for some machine models), which provides a clear view of the sewing area. For machines with adjustable stitch length and stitch width, set the stitch length and stitch width according to the look you want for your project. For more information about the Non-stick Foot, here is a video.
254	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
255	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
256	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
257	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.





## English

258	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
259	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
260	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
261	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.

## English

262	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Try various stitch length and/or width adjustments to change the look of the stitch as desired. It may be helpful to use a Satin Stitch Foot (additional accessory for some machine models) for denser stitch settings, as this foot has a groove on the underside to allow stitches to pass freely underneath. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt cotton. Be sure to use a needle that is appropriate for the type of thread you are using, and stabilizer to help support the fabric and stitches. Learn more about needles and stabilizer on the SINGER website.
263	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
264	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
265	DECORATIVE STITCH	Quilting		This decorative stitch can be sewn in parallel rows to help create loft in the layers of quilt blocks. The thread is usually in a color that matches or blends well with the fabric, so that just the quilt texture is noticeable when finished stitching. Experiment with various stitch length and stitch width settings to achieve the look you want for your project.
266	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.






**English**

267	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
268	PRAIRIE POINT STITCH	Heirloom Sewing		<p>This stitch is commonly used for heirloom sewing and vintage style projects. These stitches look best when sewn on lightweight fabrics such as organdy, organza, or batiste. It is helpful to prepare the fabric with fabric spray starch and press it so it has more "body", as the stitch is dense and also usually sewn on a single layer of fabric. Use a SINGER Hemstitching Needle (additional accessory), which helps create small "holes" in the fabric as you sew. Use a lightweight thread in the needle and bobbin, as all-purpose thread will be too thick and the holes created by the wing needle won't show as well. An Open Toe Foot (additional accessory for some machine models) can also be helpful because it provides a clear view as you sew. Press again when finished.</p>
269	PRAIRIE POINT STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
270	PRAIRIE POINT STITCH	Heirloom Sewing		<p>This stitch is commonly used for heirloom sewing and vintage style projects. These stitches look best when sewn on lightweight fabrics such as organdy, organza, or batiste. It is helpful to prepare the fabric with fabric spray starch and press it so it has more "body", as the stitch is dense and also usually sewn on a single layer of fabric. Use a SINGER Hemstitching Needle (additional accessory), which helps create small "holes" in the fabric as you sew. Use a lightweight thread in the needle and bobbin, as all-purpose thread will be too thick and the holes created by the wing needle won't show as well. An Open Toe Foot (additional accessory for some machine models) can also be helpful because it provides a clear view as you sew. Press again when finished.</p>

## English




271	PRAIRIE POINT STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
272	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
273	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
274	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
275	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.

## English





276	DECORATIVE STITCH	Smocking		<p>Sew this stitch pattern over gathered fabric to create smocking, often seen in children's clothing and even vintage apparel. This technique works best with lightweight woven fabrics, like batiste or voile. Start by sewing several rows of basting stitches - sew 1 row, then a second row 1/8" inch from the first. Skip 1/2" and repeat, continuing for the amount of basting rows needed for your project. Gather the basting threads. Place the gathered piece over a fabric interfacing or piece of organza. To sew the decorative stitch pattern, use a 30wt cotton in the needle, which will provide a hand-sewn look, and stitch over the basted rows.</p>
277	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
278	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
279	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
280	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>



## English

281	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
282	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
283	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
284	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
285	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.





## English

286	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
287	PRAIRIE POINT STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
288	PRAIRIE POINT STITCH	Heirloom Sewing		<p>This stitch is commonly used for heirloom sewing and vintage style projects. These stitches look best when sewn on lightweight fabrics such as organdy, organza, or batiste. It is helpful to prepare the fabric with fabric spray starch and press it so it has more "body", as the stitch is dense and also usually sewn on a single layer of fabric. Use a SINGER Hemstitching Needle (additional accessory), which helps create small "holes" in the fabric as you sew. Use a lightweight thread in the needle and bobbin, as all-purpose thread will be too thick and the holes created by the wing needle won't show as well. An Open Toe Foot (additional accessory for some machine models) can also be helpful because it provides a clear view as you sew. Press again when finished.</p>
289	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>





## English

290	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
291	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>
292	DECORATIVE STITCH	Edge-Joining		<p>Two fabric edges can be joined together using this decorative stitch. First, turn under and press the edge of both fabrics. An Edge Joining Foot (additional accessory for some machine models) can be used as a guide for the fabrics. Place the folded edges next to each other, one on each side of the foot's center guide, and place a piece of lightweight stabilizer underneath the area where they join. Select the length and width setting you want for your project. Sew across the area where the fabrics join, so the left movement of the needle sews on the left fabric, and the right movement of the needle sews on the right fabric. Remove the stabilizer when finished. Try using a topstitching thread and Topstitching Needle (additional accessory) for a more bold appearance to the stitches.</p>
293	DECORATIVE STITCH	Decorative Stitching		<p>Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.</p>

## English

294	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
295	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
296	DECORATIVE STITCH	Heirloom Sewing		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
297	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
298	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.

## English

299	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
300	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
301	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.
302	DECORATIVE STITCH	Decorative Stitching		Use this stitch to embellish your sewing projects with a single row, multiple rows, or even in combination with other decorative stitches. Experiment with various types of thread such as rayon thread, all-purpose thread, metallic thread, topstitching thread, or even 30wt and 12wt cotton. Use a needle that is appropriate for the type of thread you are using. It is also helpful to use a stabilizer to help support the stitches. Learn more about needles and stabilizer on the SINGER website.

English				
303	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	1	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
304	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	1	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
305	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	2	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
306	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	2	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
307	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	3	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
308	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	3	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
309	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	4	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
310	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	4	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
311	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	5	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.



English				
312	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	5	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
313	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	6	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
314	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	6	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
315	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	7	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
316	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	7	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
317	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	8	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
318	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	8	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
319	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	9	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
320	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	9	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
321	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	0	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
322	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	0	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
323	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	A	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
324	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	A	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
325	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	B	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
326	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	B	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

**English**

327	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	C	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>
328	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	C	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>
329	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	D	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>

English				
330	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	D	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
331	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	E	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
332	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	E	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
333	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	F	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
334	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	F	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
335	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	G	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.



English				
336	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	G	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
337	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	H	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
338	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	H	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
339	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	I	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
340	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	I	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
341	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	J	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
342	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	J	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
343	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	K	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
344	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	K	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

**English**

345	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	L	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
346	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	L	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
347	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	M	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
348	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	M	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
349	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	N	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
350	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	N	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
351	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	O	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
352	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	O	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
353	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	P	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
354	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	P	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
355	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Q	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
356	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Q	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
357	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	R	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
358	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	R	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
359	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	S	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.



English				
360	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	S	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
361	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	T	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
362	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	T	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
363	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	U	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
364	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	U	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
365	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	V	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
366	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	V	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
367	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	W	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
368	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	W	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

## English

369	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	X	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>
370	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	X	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>
371	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Y	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>

English				
372	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Y	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
373	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Z	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
374	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Z	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

## English

375	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Ä	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>
376	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Ä	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>
377	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Å	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>

English				
378	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	À	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
379	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Æ	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
380	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Æ	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
381	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Ñ	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
382	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Ñ	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
383	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Ö	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.



## English

384	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Ö	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>
385	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Ø	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>
386	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Ø	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>

English				
387	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Ç	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
388	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Ç	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
389	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Ğ	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
390	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Ğ	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
391	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	ı	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
392	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	ı	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
393	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	§	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
394	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	§	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
395	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Ü	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
396	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Ü	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
397	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Â	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
398	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Â	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
399	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	É	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
400	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	É	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
401	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	É	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
402	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	È	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
403	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	↑	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
404	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	↑	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
405	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	ï	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
406	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	ï	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
407	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	Ô	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.



English				
408	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	Ô	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
409	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	β	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
410	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	β	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
411	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	&	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
412	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	&	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
413	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	?	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
414	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	?	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
415	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	!	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
416	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	!	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

## English

417	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	—	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>
418	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	—	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>
419	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	,	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>

**English**

420	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	,	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>
421	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	,	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>
422	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	,	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>

## English

423	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	▪	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>
424	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	▪	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>
425	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	—	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>

**English**

426	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	—	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>
427	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	(	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>
428	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	(	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>

English				
429	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	)	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
430	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	)	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
431	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	@	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.







English				
432	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	@	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
433	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	▪ ▪	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
434	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	▪ ▪	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)

English				
435	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	▪ ,	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
436	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	▪ ,	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
437	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	\	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

## English

438	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	\	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>
439	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	/	<p>Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.</p>
440	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	/	<p>The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)</p>

English				
441	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	#	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
442	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms	#	The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
443	LETTERS & NUMBERS BLOCK FONT	Decorative Stitching	□	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





English				
444	LETTERS & NUMBERS BLOCK FONT	Sewing Fonts and Monograms		The Block Style Font includes letters, numbers, punctuation and key symbols. Create your own custom stitch sequences to personalize your projects and sew words and phrases, names, dates, and monograms. It is helpful to use a Satin Stitch Foot (additional accessory for some machine models), as this foot has a groove on the underside to allow dense stitching to pass freely underneath. Use a stabilizer under the fabric to help prevent the dense stitches from puckering the fabric. Use an all-purpose thread or 30wt cotton for a bolder look. (Note: To put a "space" between characters, use the symbol from the stitch selection that resembles the shape of a square.)
445	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
446	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
447	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
448	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	2	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
449	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	3	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
450	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	3	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
451	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	4	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





English				
452	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	4	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
453	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	5	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
454	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	5	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
455	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	6	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
456	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	6	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
457	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	7	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
458	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	7	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
459	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	8	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.







English				
460	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
461	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
462	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
463	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





**English**

464	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
465	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
466	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
467	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





## English

468	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
469	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
470	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
471	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





English				
472	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
473	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
474	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
475	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
476	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
477	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
478	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
479	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





## English

480	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
481	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
482	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
483	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





## English

484	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
485	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
486	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
487	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

## English

488	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
489	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
490	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
491	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.







English				
492	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
493	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
494	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
495	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

## English





496	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	P	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
497	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	Q	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
498	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	Q	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
499	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	R	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.



English				
500	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	R	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
501	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	S	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
502	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms	S	Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
503	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching	T	Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

## English





504	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
505	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
506	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
507	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

## English





508	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
509	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
510	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
511	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
512	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
513	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
514	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
515	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





## English





516	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
517	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
518	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
519	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

## English





520	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
521	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
522	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
523	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.







English				
524	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
525	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
526	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
527	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
528	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
529	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
530	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
531	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





## English

532	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
533	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
534	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
535	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





## English

536	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
537	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
538	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
539	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





## English

540	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
541	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
542	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
543	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.





## English

544	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
545	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
546	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
547	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.



## English



548	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
549	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
550	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
551	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.



## English

552	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
553	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
554	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
555	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.







English				
556	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
557	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
558	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
559	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.




English				
560	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
561	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
562	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
563	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.



English				
564	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
565	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
566	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
567	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.




## English

568	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
569	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
570	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
571	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
572	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
573	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
574	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
575	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
576	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
577	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
578	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
579	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
580	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
581	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
582	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
583	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

English				
584	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
585	LETTERS & NUMBERS OUTLINE FONT	Decorative Stitching		Letters, numbers and punctuation marks are not only for stitching words and phrases, but the characters can all be used creatively as well. Embellish fabric texture by sewing rows and rows of a single stitch, or create a stitch sequence to repeat over and over to add dimension to your fabric. Experiment with various thread types such as all-purpose thread, metallic thread, rayon thread and even 30wt cotton. Use a Satin Stitch Foot (additional accessory for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.
586	LETTERS & NUMBERS OUTLINE FONT	Sewing Fonts and Monograms		Use Outline Font letters, numbers and punctuation characters to create unique stitch sequences. Sew words and phrases, names, dates and monograms to personalize your projects. Use a Satin Stitch Foot (additional accessory) for some machine models) to allow the dense stitching to pass freely underneath the foot. Place a fabric stabilizer underneath the fabric, which will help prevent fabric puckering. When finished sewing, use a fine point scissor to carefully trim the connecting threads between the characters.

SINGER, the Cameo "S" Design, and SINGER is SEWING MADE EASY are exclusive trademarks of The Singer Company Limited S.à r.l., or its Affiliates. ©2020 The Singer Company Limited S.à r.l. or its Affiliates. All rights reserved.

Each model varies in its functionality and features. The descriptions for some applications may reference techniques or accessories that are not available or included with your machine model.